

CONTROL DEVICE CRANECAMERASYSTEM VH-2250

VH-5409



VH-5540



Viewing angle adjust:

- Press "Rear" to adjust the viewing angle to the front
- Press "Front" to adjust the viewing angle to the back

Zoom function:

- Press "Zoom wide" to zoom out
- Press "Zoom tele" to zoom in

Switching the camera on:

- Press and hold "Zoom tele" to switch the camera and monitor on

Switching the camera off:

- Press and hold "Zoom wide" for 10 seconds to switch the camera and monitor off

BEDIENINGS APPARAAT CAMERASYSTEEM VH-2250

VH-5409



VH-5540



Zichthoek instellen:

Druk op "Rear" om de zichthoek naar achter te draaien
Druk op "Front" om de zichthoek naar voren te draaien

Zoom functie:

Druk op "Zoom wide" om uit te zoomen
Druk op "Zoom tele" om in te zoomen

Camera inschakelen:

Druk 2 seconden lang op "Zoom tele" om de camera en monitor in te schakelen.

Camera uitschakelen:

Druk 10 seconden lang op "Zoom wide" om de camera en monitor uit te schakelen.