

## CONTROL DEVICE CRANECAMERASYSTEM VH-2250

VH-5409



VH-5540



### Viewing angle adjust:

Press "Rear" to adjust the viewing angle to the front  
Press "Front" to adjust the viewing angle to the back

### Zoom function:

Press "Zoom wide" to zoom out  
Press "Zoom tele" to zoom in

### Switching the camera on:

Press and hold "Zoom tele" to switch the camera and monitor on

### Switching the camera off:

Press and hold "Zoom wide" for 10 seconds to switch the camera and monitor off